

Quick Installation Guide

300Mbps Wireless-N PCI Adapter 300Mbps Wireless-N PCI-e Adapter

Model No.: NE-WN3500D/NE-WN3800D

Hardware Installation

Steps:

- 1. Turn off your computer and unplug the power cord from the computer.
- 2. Open the chassis, locate an available PCI or PCI Express slot (Depends on the model purchased) and removes its slot cover.
- 3. Insert the adapter into the PCI or PCI Express slot.
- 4. Secure the adapter with the screw removed in step 2.
- 5. Close the chassis and plug-in the power cord back into the computer.
- 6. Turn on the computer.

You may see the **Found New Hardware Wizard** after the adapter has been inserted. Please click "**Cancel**".

For Windows XP:

Found New Hardware Wizard		
	Welcome to the Found New Hardware Wizard	
	Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission). <u>Read our privacy policy</u>	
	Can Windows connect to Windows Update to search for software?	
	O Yes, this time only	
	Yes, now and every time I connect a device	
	 No, not this time 	
	Click Next to continue	
	< Back Next > Cancel	

For Windows Vista:



Software Installation

Caution: Product should NOT be inserted at this time. You will be asked to insert product after the software is completely installed.

Note: Screen-shot image provided below is based on Windows 7. You may see different screen on other operating systems but procedures are the same.

- A. Power on your computer and allow Windows 2000/XP/Vista/7 to load fully.
- B. Insert the installation CD into your CD-ROM drive and find the appropriate product model to install, then run "Setup.exe" program. "Ralink Wireless LAN – InstallShield Wizard" will appear on your screen, then select "I accept the terms of the license agreement", then click "Next"



C. Choose "Install driver and Ralink WLAN Utility" and click "Next".

Ralink Wireless LAN - InstallShield Wizard		
Setup Type Select the setup type that best suits your needs.		
	Choose to install	
	 Install driver and Ralink WLAN Utility Install driver only 	
Ralink		
InstallShield	< Back Next > Ca	ncel

D. Click "Install" to begin the installation of driver and utility for your adapter.



E. Click "Finish" when you see "InstallShield Wizard Complete" to finish the installation.

Ralink Wireless LAN - InstallShield Wizard	
	InstallShield Wizard Complete
	The InstallShield Wizard has successfully installed Ralink Wireless LAN. Click Finish to exit the wizard.
~	
Ralink	
InstallShield	< Back Finish Cancel

You will see "Configuration & Monitor Utility" icon appears on your system tray when the installation is completed successfully.



If you don't see the icon, we highly recommend you to restart the computer. However, if you still don't see the icon appears, please uninstall and reinstall the software again.